

Personalize Your Smartphone

A. Change the Home screen


- Click **Start** > **Settings** > **Home Screen**.

B. Set the date and time

- Click **Start** > **Settings** > **Clock & Alarm** > **Date and Time**.

C. Manage Power settings

- Click **Start** > **Settings** > **Power Management**.



Go Online and Surf the Web

Go online by turning on Wi-Fi® on your phone.



1 Click **Start** > **Comm Manager** and click the WLAN button.

2 Click **Yes**.

3 Choose the network you want to use and click **Connect**.


Note If you are connecting to a secure network connection, you may need to enter the **WEP Key** for that network connection before you can connect to it.

Use Internet Explorer® Mobile (click **Start** > **Internet Explorer**) to surf the Web.

If there is no Wi-Fi hotspot in your area, you can still connect to the Internet by using the GPRS/EDGE or dial-up service of your wireless service provider. Refer to the User Manual to learn how to connect using GPRS/EDGE or dial up.

Get E-mail Using Your Phone

Get your e-mail on your phone. Set up your phone so you can send and receive e-mails using your favorite e-mail service.



1 Click **Start** > **Messaging** > **New E-mail Account**.

2 Type in your **E-mail address** and click **Next**.

3 Click **Next**.
* If unsuccessful, you need to enter the settings manually in the succeeding screens.



4 Type in **Your Name** and **Account display name**. Click **Next**.

5 Type in the **User name** and **Password** for the e-mail account. Click **Next**.

6 Select the frequency to send and receive e-mail. Click **Finish**.

You can synchronize your phone with your company's Microsoft Exchange server so you get your company e-mails on your phone.

Refer to the User Manual to learn how to get your company e-mails on your phone.

Read Me First

This **Read Me First** will help you get started with using your Microsoft® Windows Mobile® 6 Standard powered phone. We recommend that you have this guide handy when you start using your phone.

For a more complete reference, consult the User Manual that came with the phone.



Secure Your Phone


Protect your phone from unauthorized access by enabling the SIM lock and/or Device lock.

A. To enable the SIM lock

- Click **Start** > **Settings** > **Security** > **Enable SIM PIN**.


B. To enable device lock

- Click **Start** > **Settings** > **Security** > **Device Lock**.
- Select the **Prompt if device unused** for check box and enter the time you want.
- Select the **Password type**.
- Enter and confirm the password, then click **Done**.



Take a Picture


Take out your phone and capture those precious moments.



The photo is automatically saved in your phone after you shoot unless you choose to delete () it in the Review screen. Press () to send the photo via MMS or e-mail. Refer to the User Manual to learn more about the Camera.

What's in the Box

These are the items that you should find inside the box.




- Smartphone
- USB Sync Cable
- AC Adapter
- Headset
- Getting Started Disc
- Battery
- User Manual, Read Me First

www.htc.com




Before You Turn On ...


A. Install the SIM Card




B. Install a microSD™ card (not included in box)



C. Install the battery



D. Turning on/off the phone



Keypad or Keyboard ... Your Choice

The phone comes with a keypad and a slide-out QWERTY keyboard. Use either input method to enter information or type messages on your phone.

To enter contacts into your phone

- On the Home screen, click **Contacts** > **New** > **Outlook Contact** or **SIM Contact**.
- Enter the contact information and click **Done**.





Synchronize Your Phone and PC

Synchronize your PC with your phone to keep information up-to-date on your phone.

Set up Windows® Mobile Device Center on Windows Vista™


- Connect your phone to your PC. Windows Mobile Device Center will open. On the screen, click **Set up your device**.
- Select the information you want to synchronize.
- Click **Next**.
- Type in a name for your Smartphone.
- Click **Set Up**.

When you finish the wizard, Windows Mobile Device Center synchronizes your phone automatically. Notice that Outlook e-mails and other information will appear on your phone after synchronization.




For PC's with operating systems other than Windows Vista, refer to the User Manual to learn how to install and set up ActiveSync®.

The Smartphone



Home Screen

This bar displays various indicators that inform you of message notifications, network status, battery power, signal strength, and more.





This area lets you view information such as missed calls, appointments, and messages. It also lets you access recently used programs on your phone. Use the NAVIGATION CONTROL to scroll through the items here. Press CENTER OK to open the associated program.

This bar lets you access the Start menu and open Contacts, Call History, or Messages. Click the left or right Soft Key to open the associated program.

Send a Text Message

Send out short text messages to another mobile phone.

- Click **Start** > **Messaging** > **Text Messages**.



Make that First Call

Do one of the following:

- Enter the number of the contact using the keypad and press ().
- Start pressing the contact's name or number and the matching contacts will appear on screen. Use the NAVIGATION CONTROL to select the contact and press ().



For hands-free operation, connect your phone with the wired headset or Bluetooth® headset (not included) to your phone.

To learn how to connect a Bluetooth headset to your phone, refer to the User Manual.